


## How to setup a working UDP connection to X-plane v10.x:

First, start X-Plane and take something to drink ☺.


Choose for “Net Connections” and fill in the IP- address (*Note: The IP- address of the remote computer depends on your network!*) of the remote computer (on the same sub-net!) and the used port as shown:




The UDP port settings are on the same page in X-Plane v10.x Fill in the used port- numbers like this example.

This manual describes only the configuration of the UDP connection, not the configuration of the gauges or the USB settings!

On the remote computer start the Gstep software and click on “configure”:



Set the IP- adress of the X-Plane computer and the used port- numbers:



Click on SET and Save / Load to save the configuration.

If you had something changed in X-Plane you must shut- down X-Plane and restart it and drink something again 😊.

When you has follow these steps it must be work.